

Thank You for Purchasing the MAF LLC Lower Radiator Support!

Installation instructions for 79-04 Mustangs

1. Raise the Vehicle off the ground and safely support on Jack Stands or put the car on a lift.
2. Remove The Radiator, Power Steering lines and Air Conditioning Lines – Condenser
3. Take a tape measure and measure off of something (K member/engine) to the factory Radiator Pads) and write that dimension down.
4. Take a Saw, cut off wheel and remove the factory Radiator core support by cutting it off flush to the bottom of the frame.
5. Remove all the paint and prep the metal for welding with in 1" where the new radiator core support will go.
6. Set the Radiator support in place on the frame rails and support with a floor jack.
7. Use the dimension from step 3 and slide the radiator core support forward or backward.
(This will put the radiator in the same place as it was before)
8. Weld in place.
9. Paint
10. Reinstall the radiator and other pieces removed from step 2.

NOTE: If you are installing a lower Radiator core support with a tubular from bumper, and your car is a **79-89**, your front bumper plates must be cut and welded to the factory radiator core support.

